

# Viltrox EF-Z Lens Mount Adapter Ring

## Compatible List

Canon Zoom Lens	Canon EF 17-40mm F4 L	
	Canon EF 16-35mm F2.8 L II USM	
	Canon EF 24-70mm F2.8 L II USM	
	Canon EF 24-105mm F4 L IS USM MACEO	
	Canon EF 28-105mm F3.5-4.5 MACRO	
	Canon EF 20-35mm F3.5-4.5 MACRO	
	Canon EF 70-200mm F4 L IS USM	
	Canon EF 70-200mm F2.8 L IS II USM	
	Canon EF 70-200mm F4 L USM	
	Canon EF 70-300mm F4-5.6 L IS USM MACEO	
	Canon EF 70-300mm F4-5.6 IS II USM	
	Canon EF 70-300mm F4-5.6 IS USM	
	Canon EF-S 17-85mm F4-5.6 IS USM	
	Canon EF-S 18-135mm F3.5-5.6 IS STM	
	Canon EF-S 18-55mm F3.5-5.6 IS STM MACRO	
	Canon EF-S 18-200mm F3.5-5.6 IS	
	Canon EF-S 15-85mm F3.5-5.6 IS USM	
	Canon EF-S 55-250mm 1:4-5.6 IS STM	
	on Prime Lens	Canon TS-E 24mm F3.5 L II(MF)
		Canon EF 24mm F1.4 L II USM
Canon EF 35mm 1:1.4 L		
Canon EF 35mm 1:1.4 L II USM		
Canon EF 40mm F2.8 STM MACR		
Canon EF 50mm F2.5 COMPACT-MACRO		
Canon EF 50mm F1.4		
Canon EF 50mm F1.8 STM		
Canon EF 50mm F1.2 L USM		
Canon EF 85mm F1.2 L II USM		
Canon EF 85mm F1.8		
Canon EF 100mm F2.8 L IS USM MACRO		
Canon EF 135mm F2 L USM		
Canon EF 200mm F2.8 L II		

TAMRON

Tamron SP 35mm F/1.4 Di USD F045  
Tamron SP 35mm F1.8 Di VC USM F012  
(Continuous focus and video focus will be occasional crashes)  
Tamron SP 85mm F/1.8 Di VC USD F016  
(There will be occasional crashes)  
Tamron SP 90mm F/2.8 Di MACRO 1:1 VC USD F017  
Tamron 10-24mmF/3.5-4.5 Di II VC HLD B023  
Tamron SP 15-30mm F/2.8 USD Di A012  
Tamron AF 17-50mm F2.8 IF A16 XR DiII SP  
(Continuous focus and video focus will be occasional crashes)  
Tamron SP AF ASPHERICAL Di LD (IF) 17-35mm 1:2.8-4 A05  
Tamron AF 28-75mm f/2.8 {IF}MACRO A09 LD XR Di SP  
(Continuous focus and video focus will be occasional crashes)  
Tamron 35-150mm F2.8-4 DI VS OSD A043  
Tamron 70-210mm F/4 Di VC USD HA034  
Tamron SP 70-200mm F/2.8 Di VC USD G2 A025  
Tamron SP 150-600mm F5-6.3 USD Di A011  
Tamron SP 70-300mm F/4-5.6 Di A005  
(Continuous focus and video focus will be occasional crashes)  
Tamron SP 70-200mm f/2.8 {IF}MACRO A001 LD Di  
(Continuous focus and video focus will be occasional crashes)

SIGMA

SIGMA A 20mm F1.4 DG 015  
SIGMA A 24mm 1:1.4 DG 015  
SIGMA A 30mm F1.4 DC 013  
SIGMA A 35mm F1.4 DG 012  
SIGMA A 50mm F1.4 DG 014  
SIGMA A 85mm F1.4 DG 016  
SIGMA A 105mm F1.4 DG 018  
SIGMA A 135mm F1.8 DG 017  
SIGMA A 18-35mm F1.8 DC 013  
SIGMA A 50-100mm 1:1.8 DC 016  
SIGMA 50mm F1.4 DG HSM  
SIGMA 10-20mm F3.5 DC HSM  
(A flash screen appears when focusing)  
SIGMA 12-24mm F4.5-5.6 II DG HSM  
SIGMA 70-200mm F:2.8 APO DG HSM EX

TOKINA

TOKINA SD 11-16mm F2.8 IF DX II AT-X PRO